

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS


For Models: LEC6848AW2, LEC6848AN2 (White) (Almond)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3397545	Panel, Rear Console	12	339229 339230	Hinge, R.H. Hinge, L.H.	48	3396145	Timer Knob Assembly
2	693994 693995	Screw, Hex Head Screw, Hex Head	13 15	688983 3395683	Screw, 8–15 x 5/8 Housing, Connector	49	3396175	Button, Push To Start
4	3358531	Cap, End (L.H.) White	16		(Motor) Top	50 51	689180 343641	Clip, Retainer Screw, 10–16 x 1/2
5	3358532 688805	Almond Clip		3396022 3396023	White Almond	52	3396033	Wire, Jumper (Signal Bypass)
6 7	3353145 694419	Screw, Console Buzzer, Mini	21 29	3397273 3390646	Timer, 60 Hz. Screw, Mounting	53 54	3396295	Bracket, Control Panel, Control
8	3358516	Cap, End (R.H.) White	30	357213	(8–18 x 5/16) Nut, Push–In (2)		3398507 3398508	White Almond
9	3358517 3396238	Almond Switch,	31 32	3399673 3390537	Harness, Wiring Control,	68	3393811	Wire, Jumper Violet
10	349639	Clean Touch Screen, Lint	33	3391885	Electronic Connector, Edge	72	3393812 690853	Blue Wire, Ground
11	343033	Cover, Lint Screen	39	3395395	Switch, Push-To-Start	73 74	3394427 3397269	Clip, Harness
	688150 689310	White Almond			Fu511-10-Start	/4	3391209	Connector, Timer

LITERATURE AND OPTIONAL PARTS

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
LITERATURE PARTS			OPTIONAL PARTS NOT INCLUDED					
			PAIN	NT, TOUC	H-UP (1/2oz.)	PAIN	IT, BULK	(1 qt.)
LIT	3397597	Instructions, Installation						
LIT	3396303	Use & Care Guide		72017	White		799344	White (Uncut)
LIT	3399692	Label. Wiring Diagram		72107	Almond		978883	Almond (Uncut)
		-	PAIN	IT, PRES	SURIZED SPRAY			
Following May Be Purchased			(13 c	z.)				
DO-IT-YOURSELF			\(\cdot \cdot \cd	 /				
REPAIR MANUALS								
				350930	White			
				350956	Almond			
LI	T677818	Dryer		350938	Primer, Gray			

CABINET PARTS




CABINET PARTS

For Models: LEC6848AW2, LEC6848AN2 (White) (Almond)

Illus.	Part		Illus	Part	, ,	Hllus	Part	
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
2	343641	Screw, 10-16 x 1/2	19	98234	Clip, Ground	38	692493	Seal & Bearing
4	238614	Bumper	20	690363	Lock, Front Top (2)	30	032433	Assembly
5	3396795	Cover, Block	21		Panel, Front	39	279393	Terminal Block
6	342043	Screw, 10-32 x 1/2		695620	White			Kit (For
7	3396805	Panel, Rear		695621	Almond			Terminal Block)
8	3393657	Restrainer, Belt	23	685203	Clip, Felt Pad (3)	40	697776	Screw, 10–16 x 1/2
9 10	691581 347207	Lever, Door Switch	24	690081	Catch, Door Assembly	41 51	690261 238088	Block, Terminal
11	98129	Switch, Door Screw,	25	693994	Screw, Hex	53	691366	Hinge, Top (2) Idler & Pulley
11	90129	6-20 x 1-3/8	20	000004	Washer Head (5)	55	091300	Assembly
13	3357011	Screw, 10-16 x 1/2	26	337189	Clip, Hinge (2) (56	660996	Belt, Drive
14	692495	Spring, Door (2)	27	694091	Screw (6)	57	348780	Base, Motor
15	3394083	Clip, Front	28	692498	Hinge, R.H.	58	172455	Bolt,
		Panel (2)		692501	Hinge, L.H.			5/16-18 x 3/4
16	3392100	Foot, Dryer	31	98997	Clip, Harness	59	3389627	Pulley, 60 Hz.
	279810	Foot-Optional	33 35	696144 695737	Strike, Door Door, Rear	62	3395652	Motor Assembly
		(Extended Length	36	093737	Door, Front	63	660658	60 Hz.
		Package of 2) (Not Included)	30	3393549	White	63	000000	Clamp, Motor (2) 343481 (Alt.)
17	279318	Terminal, Tinned		3393550	Almond			685441 (Alt.)
	270010	& Brass (3)	37		Handle, Door	67	3390731	Seal, Door
		(Includes Illus. 39)		690270	White	87	3393008	Screw, 10-16 x 1/2
18		Cabinet		690271	Almond			,
		(Includes Illus.						
		Nos. 5,7,15,16,						
	0000505	41, & 57)						
	3399585	White						
	3399586	Almond	I			I		

BULKHEAD PARTS

For Models: LEC6848AW2, LEC6848AN2 (White) (Almond)



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	348368	Lint Chute	12	3398161	Clip	30	348861	Pad. Sensor
		Assembly	13	343641	Screw, 10-16 x 1/2	31	348859	Electrode, Inside
2	3400800	Screw, 8-18 x 3/4	14	695547	Box, Heater	32	348860	Electrode, Outside
3	3388703	Washer-Support	15	3390291	Thermostat, 250°F	41	690997	Ring, Tri
4	347139	Seal, Lint			(121.1°C)	42	3399506	Shaft, L.H.
		Chute	16	98460	Nut, Push-In (2)	43	3399507	Shaft, R.H.
5	90767	Screw, 8A x 3/8	17	660982	Element, Heater	44	3397588	Roller, Support
6	696302	Shield, Exhaust			693300 (Alt.)	46	348197	Washer, Support
7	3392519	Thermal Fuse			693298 (Alt.)	47	3359452	Nut, 3/8-16
8	3387134	Thermostat,			693062 (Alt.)	48	3396793	Bulkhead
		Internal-Bias	18	686889	Pad, Cabinet	62	692526	Ring, Bearing
9	3398671	Thermal, Cut-Off	19	279457	Wire Kit, Terminal	63	97787	Screw, 11-16 x 7/8
		(Hi–Limit			(For Heater	66	347885	Seal, Rear Drum
		Thermostat Illus.			Element Wiring	67	695587	Drum Assembly
		No.15 Included)			Harness Repair)	68	692490	Baffle, Drum (2)
10	694089	Wheel, Blower	22	3392123	Seal, Blower	69	348944	Bracket, Support
		(Includes Illus.	23	695239	Screw, 8-18 x 3/8	70	90296	Clip
		No. 22)	28	342267	Clip, Sensor	71	692491	Baffle, Drum (1)
11	695081	Housing, Blower	29	298877	Washer, Insulated	73	339956	Seal